



# 134

## RECEIVER HITCH

### Dodge Ram 1500 Quad Cab, Crew Cab 2009 & Up

#### INSTALLATION INSTRUCTIONS

1. **Check** all parts. **Read and understand** instructions completely before beginning installation.

- |                                         |                                  |                                          |
|-----------------------------------------|----------------------------------|------------------------------------------|
| <b>2) Hangers</b>                       | <b>2) 1/2" Lockwashers</b>       | <b>8) 14mm - 2.00mm x 40mm Hex Bolts</b> |
| <b>1) Center Section</b>                | <b>2) 1/2" - 13 Hex Nut</b>      | <b>8) 14mm Lockwashers</b>               |
| <b>2) 1/2" - 13 x 2" Carriage Bolts</b> | <b>2) 1/2" HD Flatwasher</b>     | <b>4) 14mm Flat Washers</b>              |
| <b>2) 1/4" Sq. Hole Spacers</b>         | <b>8) 14mm - 2.0 mm Hex Nuts</b> |                                          |

2. **Remove** the two 14mm - 1.50 hex bolts on the bottom of each frame rail that hold the rear cross section in place. Save those bolts, you will reuse them.

3. **Clean** the underside of the frame rails of all debris.

4. **Put** the square hole spacer over the 1/2" - 13 x 2" carriage bolt and fish wire the two to the large hole just forward of the rear cross section. (As you pull the bolt and square hole spacer forward through the frame you may need to put your finger in the large hole in the side of the frame rail and help the bolt and spacer past the weld nuts in that area.)

5. **Raise** the hitch hanger into position, making sure you do not push the 1/2" carriage back into the frame.

6. **Hold** the hanger in place with the two 14mm - 1.50 bolts you had removed. Hand start the bolts to be sure they screw in freely.

7. **Put** the 1/2" HD flat washer , 1/2" lock washer and 1/2" nut on the carriage bolt you fished through the frame.

8. **Slip** the 14mm - 2.00 x 40mm hex bolt with a 14mm flat washer through the rear cross section side plate and hanger. Slip a 14mm flat washer and lock washer over the bolt. Then put the 14mm nut on. Leave all the bolts and nuts loose.

9. **Install** the other side the same way

10. **Lift** the center section into position between the two hangers. Secure with three 14mm - 2.00 x 40mm hex bolts, 14mm lock washers, and 14mm - 2.00 hex nuts on each side. Snug all bolts and nuts.

11. **Torque** all bolts starting with the hangers. 1/2" bolts to 75 ft./lbs., 14mm bolts to 100 ft./lbs.

<b>GROSS LOAD</b>		
HITCH TYPE	MAX TRL WT (LB)	MAX TONGUE WT (LB)
WEIGHT DISTRIBUTION	<b>10,000</b>	<b>1000</b>
WEIGHT CARRYING	<b>6,000</b>	<b>600</b>

**Do not exceed vehicle manufacturer's recommended towing capacity**

The manufacturer warrants this product to be free of defects in material or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, the manufacturer may repair or replace the product, at its option, when product is returned, prepaid, with proof of purchase to the manufacturer. Alteration to, misuse of, or improper installation of product voids this warranty. Manufacturers liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

Quality S Manufacturing, Inc., Phoenix, AZ

