



INSTALLATION INSTRUCTIONS

BULL BAR PART# B35-6001 / 35-6001
2006-10 RIDGELINE

PART LIST :

1	GRILLE GUARD	1	
2	HEX BOLT	4	M12*30
3	FLAT WASHER	8	φ 12
4	SPRING WASHER	4	φ 12
5	HEX NUT	4	M12
6	MOUNTING BRACKET	2	

STEP 1. PLEASE PROTECT YOUR PRODUCT FROM BEING SCRATCHED DURING THE PROCESS OF INSTALLING THE GRILLE GUARD).

STEP 2. FIRST, TAKE OFF THE HEX BOLT ON THE VEHICLE .

STEP 3. BE ATTENTION TO DISTINGUISH LEFT AND RIGHT MOUNTS, THEN INSTALLATE THEM (DO NOT SCREW THE BOLTS TIGHTLY) , AFTER THAT COMES TO THE GRILLE GUARD. PUT IT IN PLACE. IN THE END, SCREW ALL THE BOLTS TIGHTLY.

