



INSTALLATION INSTRUCTIONS
2007-11 JEEP WRANGLER 4 DOOR (NOT WITH FACTORY ROCKER)
PART # 35700 / 35700-2

PARTS LIST

- | | |
|-------------------------------------|-------------------------------------|
| (1) Driver Side Bar | (1) Passenger Side Bar |
| (2) Front Brackets (Driver/Pass) | (2) Middle Bracket (Driver/Pass) |
| (2) Rear Bracket (Driver/Pass) | (12) M6X25mm Button Head Cap Bolts |
| (12) M6 Nylock nuts | (24) M6X22mmX3mm thick Flat Washers |
| (2) M8X35mm Hex Head Bolts | (12) M8X25mm Hex Head Bolts |
| (14) M8 Lock Washers | (2) M8X25mmX3mm Thick Flat Washers |
| (12) M8X15mmX3mm Thick Flat Washers | (4) M10X35mm Hex Head Bolts |
| (4) M10 Nut Plates | (4) M10 Lock Washers |
| (4) M10X30mmX3mm thick Flat Washers | |

PROCEDURE:

1. **REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY.**
2. Locate, remove and set aside the front, middle and rear bar mounts, and the hardware kit.
3. Install the three nut plates into the frame openings (Fig 1) with the nut facing up
4. Attach the front, middle and rear bar mount on the driver side with one of the 12MM bolts, lock washer and washer. (Fig 2)
5. Install the black round head bolts and 6MM lock nuts (Fig 3)
6. Attach the middle and rear bar brackets using the same fasteners in number 4 above.
7. Place the bar on the brackets and install the 8MM bolts and lock washers (Fig 4)
8. Align the bar and tighten all the fasteners (Fig 5)
9. Repeat operation on passenger side.



Fig 1. Note that nut should be installed facing up. Photo shows nut facing down



Fig 2

Fig 3



Fig 4



Fig 5

